

Power Brake Exchange

260 Phelan Ave. San Jose, Ca. 95112 Ph. (408) 292-1305 Fax (408) 294-6817

Technical Bulletin TB - 1 Remote Reservoir Preloading Instructions

Please make sure you fill this reservoir first so air will be less likely trapped inside.



1. Make sure Engine is off.
2. Take Power Steering Pump and fill reservoir on pump first.
3. Fill the remote reservoir to the full line. Make sure fluid is flowing out of the line.
4. Next connect the steering line from the remote reservoir to the already filled pump.
5. Make sure it drains from the pressure fitting, before installing the pressure hose.
6. Then install the pressure hose and bleed the system.
7. Turn Engine on

**Please Make Sure you use GM
Power Steering Fluid
DO NOT USE Transmission Fluid
under any circumstances.**